



Bed Head DIY Pack Instructions

Pack Contents

- 1 x Panel of your choice
- 1 x full length Border
- 2 x half length Borders
- 1 x full length Cornice Mounting Strips
- 2 x smaller lengths of Cornice Mounting Strip
- 2 x corner rosettes
- 1 x pack of 20 nails

Tools Required

- Plywood/MDF Timber lengths cut to size
- Marking pen
- Tin snips
- Liquid Nails
- Wooden moulding tools
- Hammer
- Drill & suitable screws

CAUTION SHOULD BE USED AT ALL TIMES AS METAL EDGES ARE VERY SHARP.

Installation instructions are a guide only, all care and no responsibility will be undertaken by Pressed Tin Panels® for incorrect assembly of the bed head.

If further assistance is required please phone 02 6332 1738.

NOTE: Ply / MDF board needs to be cut to desired size, i.e. width of panel plus width of both borders. Lengths of MDF need to be cut to desired length to create legs, then screwed and glued into place at around approx one quarter total width from each end.

Installation

1. Lay the Cornice Mounting Strips around the edge of the base board with the rolled edge running around the outside. Glue and nail/staple in place, this helps to hold the Border in place.



2. Lay the Borders around along the inside of the mounting strips with the flat 'under' edge towards the centre of the base board—the full length border at the top and the two half lengths at each side.

3. Place Corner Rosette into position at each corner join, again slipping the outer edges underneath the mounting strip. Once you are happy with the position of the rosettes and the borders, you can glue and nail the border into place.



4. Now nail the Rosette on the inside corner—it will be covered by the main panel. Repeat for the second rosette.



5. Once Mounting strips, borders and Rosettes are securely in place 'check measure' the space for the centre panel. Trim panel, corners etc if necessary.
6. Apply Liquid Nails to base board generously, be sure not to go too close to the edge of the border to avoid any excess glue seeping through the joint. Place your trimmed panel onto the prepared base board, levelling as you go. Apply pressure across the entire panel with anything handy, as pictured, as the glue dries.



7. Your Pressed Tin Panels® Bed Head is now complete, a clear sealer can be applied or a coat of primer and your choice of paint effect may also be applied.

